


Technical Reference

For Multipurpose Room

inquiry :
Nakano Support Desk
(ext. 8072)
(03-5343-8072)

! Beginning !

Press ⑥ button to turn on the power after unlocked console desk by key.




Projector

PC

BD/DVD Player

MIC



to use the microphone

Step: ⑨ → ② → ④ and ⑤

- ⑨ Take out the microphone.
- ② Connect to power cable to turn on.
- ④ and ⑤ Adjust the sound level turn 「MIC」 knob.



To use the PC in the cabinet

Step: ③ → ⑦ → ④ and ⑤

- ③ Press 「PC」 button.
 - ⑦ Start the PC.
 - ④ and ⑤ Adjust the sound level turn 「AV」 knob.
- ※to connect to the internet, "Kyoutu-Ninsho" System Account (your Faculty Number/Password) is needed.



To play CD,DVD,BD



Step: ③ → ⑧ → ④ and ⑤

- ③ Press 「BD」 button.
- ⑧ Insert the disk, press play button.
- ④ and ⑤ Adjust the sound level.



to use CD radio-cassette

Step: ③ → ① → ④ and ⑤

- ③ Press AV button,
- ① Connect CD radio-cassette to control panel using audio cable. Set the cassette tape, press play button.
- ④ and ⑤ Adjust the sound level.

! After Use !


Press ⑥ power button to close the cabinet and please make sure the cabinet is locked.

You can download the manual from the classroom introduction page on the 'Nakano Media Service' web site.
(http://www.meiji.ac.jp/nksd/facility_class-info.html)

Technical Reference

For Multipurpose Room

inquiry :
Nakano Support Desk
(ext. 8072)
(03-5343-8072)



To use your own PC

Step: ⑮ or ⑯ → ⑱ → ③ → ④ and ⑤

⑮ or ⑯ Connect your own PC to the control panel using RGB and audio cable or HDMI cable.

⑱ Connect your own PC to the LAN port ⑱ (next to screen) using LAN cable. (※1)

③ When you are using RGB cable Press 「RGB」button.

When you are using HDMI cable Press 「HDMI」button.

Please change the projection mode(※2) of your own PC. If needed.

④ and ⑤ Adjust the sound level turn 「AV」knob.

※1 To connect to the internet, "Kyoutu-Ninsho" System Account (your Faculty Number/Password) is needed.

※2 Press [Windows] + [P] Key to change the projection mode (the process depends on the type of your PC)



To use the projector

Step: ⑫ → ⑬ → ⑩ → ⑰ → ⑭

⑬⑩ Connect power cable to plug socket and press ⑩ button after lighting red ⑬.

※⑬ If unable to see lighting red ⑬, press button ⑩ after turn main power ⑫ on.

⑰ Press 「Down」button to start using screen.

⑭ Adjust the image on the screen from the projector as follows.

* Unlock the shift lever by turning it counterclockwise.

* Adjust the position of the image on the screen by using shift lever.

* Adjust the level of zoom and focus by turning "Zoom" and "Focus" ring.

