



# Technical reference for room 205

Inquiry : Nakano Support Desk  
(ext.8072)  
(03-5343-8072)

manuals are on the web site.  
[http://www.meiji.ac.jp/nksd/facility\\_mediaclass-info.html](http://www.meiji.ac.jp/nksd/facility_mediaclass-info.html)



**1** press [power] button on the console panel to turn on the system.

**2** to project sth onto the center monitor, press [center monitor power] button.

**3** select the sources which you are using.

name	equipment
PC	computer
BD	BD/DVD/CD player
HDMI	bring-in equipment
RGB	
AV	rental equipment
OHC	OHC

**4** to use bring-in/rental equipment connect with cables below.

- HDMI·RGB·Audio·LAN cables placed in class permanently.
- plug adapter for Apple, and other cables. please borrow from faculty room.

**5** please adjust the Audio-Visual volume knob, before turning on the power of the equipment.  
「●」is the standard position.

**6** to adjust the volume for wireless microphone, use [MIC] volume knob.  
「●」is the standard position.

**7** After use... please set the volume knob [microphone/Audio-Visual] to a standard position 「●」

- press [power] button and check that all the equipment power is out.

to output the computer sound from the speaker  
press [speaker] button in the PC@LL system.

For more details see the PC@LL manual