OHC

Ext.

Wireless Mic / Pin Mic

PC@LL Display

Blu-ray Player

Control Panel

PC@LL Manual

Cables
Installed PC
PC@LL Device

① Power

② Power

③ Control

Volume
MIC   AV
0 10   0 10

Screen
UP
STOP
DOWN

Projector／Display Output Selection
PC | BD | HDMI | RGB | | 書画カメラ | | | OFF

Center Monitor Output Selection
PC | BD | HDMI | RGB | | 書画カメラ | | | OFF

Input
HDMI | RGB | LAN | MIC

Output
HDMI

---

①
Press Power to turn on the system

②
Press Power to use Projector and Display

③
Select source
PC = Installed PC
BD = Blu-ray Player
HDMI = Personal Device
RGB = Analog Device
書画カメラ = Document Camera

Input = Inputs video/audio from personal laptops, etc.
HDMI = Device via HDMI
RGB = Analog device input
LAN = Network LAN
MIC = Wired Mic

Output
Outputs the projected video and classroom audio

For PC@LL, please refer to the manual provided in the classroom.