


MIC



Cam Controller



Ext.



Control Panel



Installed Laptop



Cables, Document Camera, and BD/DVD Player



1

Touch the IC card to the reader on top to unlock.



2

Turn on installed laptop



3

Take wireless mic from drawer



4

Turn on projector and display



HDMI In = Connect external devices

HDMI Out = Outputs the projected video and classroom audio
(Can be used for Zoom streaming or recording tablet/BD video and audio)

Select the source
PC = Installed laptop
BD = BD/DVD Player
HDMI = Personal device
RGB = Analog input device
CAM1 = Audience Camera
CAM2 = Board Camera



When using the camera, match the CAM on the console and controller.

Example: To show the blackboard, set CAM2 on both the console and controller.