


Ext.



Mic



Installed Laptop

Control Panel

Document Camera

BD Player

Cable



- 1 Tap IC card on reader to unlock



- 2 Turn on the installed laptop
(or connect your laptop via cable)



HDMI In = Inputs video/audio from personal laptops, etc.
HDMI Out = Outputs the projected video and classroom audio
Audio IN = Analog audio input
MIC = Wired microphone
RGB = Analog device input

- 3 Select the source to display


Permanent computer = Installed laptop
BD player = BD Player
HDMI Input1, Input2 = Device via HDMI
OHC = Document camera
RGB Input = Analog device input

- 4 Select where to display

Right Screen = Audience right
Left Screen = Audience left
Preview Monitor = Preview Monitor

- 5 Adjust the volume

- 6 Take wireless mic from drawer



After Use:

Return mic to stand for charging.
Turn off the PC/BD player, then close the console.